

GAMA DISNEY

Mânere pentru camere de copii

NR. CRT.	COD	ÎNTRU CENTRE	LUNGIME	ÎNĂLȚIME	GROSIME	FINISAJ	BUC./ CUTIE
1	E001	-	37	31	39	ABS-PLASTIC, Multicolor	10
2	E002	-	43	31	37	ABS-PLASTIC, Multicolor	10
3	E003	-	48	35	28	ABS-PLASTIC, Multicolor	10
4	E004	-	48	42	26	ABS-PLASTIC, Multicolor	10
5	E005	-	36	27	31	ABS-PLASTIC, Multicolor	10
6	E006	-	34	38	46	ABS-PLASTIC, Multicolor	10
7	E009	-	40	37	43	ABS-PLASTIC, Multicolor	10
8	E122 TR	-	-	25	30	ABS-PLASTIC, Transparent	25
9	E122 RE	-	-	25	30	ABS-PLASTIC, Roșu	
10	E122 GR	-	-	25	30	ABS-PLASTIC, Verde	
11	E122 OR	-	-	25	30	ABS-PLASTIC, Portocaliu	
12	E123 TR	96	126	25	20	ABS-PLASTIC, Transparent	
13	E123 RE	96	126	25	20	ABS-PLASTIC, Roșu	
14	E123 GR	96	126	25	20	ABS-PLASTIC, Verde	
15	E123 OR	96	126	25	20	ABS-PLASTIC, Portocaliu	



GAMA EMOTIONS

Mânere pentru camere de copii

NR. CRT.	COD	ÎNTRÉ CENTRE	LUNGIME	ÎNĂLŢIME	GROSIME	FINISAJ	BUC./ CUTIE
1	E126	-	83	56	25	ABS-PLASTIC, Multicolor	10
2	E133	-	81	65	25	ABS-PLASTIC, Multicolor	10
3	E139	-	84	67	25	ABS-PLASTIC, Multicolor	10
4	E140	-	53	77	25	ABS-PLASTIC, Multicolor	10
5	E141	-	80	48	25	ABS-PLASTIC, Multicolor	10
6	E144	-	56	66	25	ABS-PLASTIC, Multicolor	10
7	E145	-	81	67	25	ABS-PLASTIC, Multicolor	10
8	E 147	-	64	71	25	ABS-PLASTIC, Multicolor	10



1



2



3



4



5



6



7



8

